Alphabetical index Alphabetical index

Α	A/C	248
	ABS	214
	ACCESSORY mode	149
	Active stabilizer suspension	
	system	214
	Adaptive variable	
	suspension system	213
	Air conditioning system	
	Air conditioning filter	469
	Automatic air conditioning	
	system	248
	Airbags	
	Airbag operating conditions	106
	Airbag precautions for	
	your child	110
	Airbag warning light	511
	Curtain shield airbag	
	precautions	113
	General airbag precautions	110
	Locations of airbags	103
	Modification and disposal of	
	airbags	114
	Proper driving posture	101
	Side airbag precautions	110
	Side and curtain shield airbags	5
	operating conditions	106
	SRS airbags	103
	Alarm	98
	Antenna	267
	Anti-lock brake system	214
	Armrest	388
	Ashtrays	383
	Audio input	319

Audio system	
Antenna	267
Audio input	319
Cassette player	270
CD player/changer	274
DVD information	302
DVD player/changer	283
DVD video/audio	286
MP3/WMA disc	279
Optimal use	314
Portable music player	319
Radio	261
Steering switches	320
Video CD	298
Automatic headlight leveling	
system	171
Automatic light control system.	169
Back-up lights	
Back-up lights Wattage	573
Wattage	
Wattage	
Wattage	447
Wattage Battery 12 volt battery Checking Hybrid battery	447 447
Wattage	447 447
Wattage Battery 12 volt battery Checking Hybrid battery (Traction battery) If the 12 volt battery is	447 447 28
Wattage	447 447 28
Wattage Battery 12 volt battery Checking Hybrid battery (Traction battery) If the 12 volt battery is discharged Preparing and checking	447 447 28 553
Wattage Battery 12 volt battery Checking Hybrid battery (Traction battery) If the 12 volt battery is discharged Preparing and checking before winter	447 28 553
Wattage Battery 12 volt battery Checking Hybrid battery (Traction battery) If the 12 volt battery is discharged Preparing and checking	447 28 553
Wattage Battery 12 volt battery Checking Hybrid battery (Traction battery) If the 12 volt battery is discharged Preparing and checking before winter Bluetooth® Brake	447 28 553 232
Wattage	447 28 553 232 328
Wattage Battery 12 volt battery Checking Hybrid battery (Traction battery) If the 12 volt battery is discharged Preparing and checking before winter Bluetooth® Brake	447 28 553 232 328 446

2	Care	
	Exterior420	
	Interior	
	Seat belts424	
	Cargo capacity227	
	Cargo hooks392	
	CD player/changer274	
	Chains233	
	Child-protectors55	
	Child restraint system	
	Definition121	
	Installation125	
	Installing CRS with lower	
	anchors126	
	Installing CRS with seatbelts128	
	Installing CRS with top straps133	
	Child safety	
	Airbag precautions110	
	Airbag precautions449, 556	
	Battery precautions449, 556	
	Battery precautions449, 556 Child restraint system121	
	Battery precautions449, 556 Child restraint system121 Child-protectors55	
	Battery precautions449, 556 Child restraint system55 Child-protectors55 How your child should wear	
	Battery precautions449, 556 Child restraint system55 Child-protectors55 How your child should wear the seatbelt77	
	Battery precautions449, 556 Child restraint system55 Child-protectors55 How your child should wear the seatbelt	
	Battery precautions	

	Cleaning	
	Exterior	420
	Interior	423
	Seat belts	424
	Clock	38
	Coin holder	377
	Compass	400
	Condenser	445
	Console box	374
	Cooling system	
	Engine overheating	557
	Cruise control	
	Cruise control	179
	Dynamic radar cruise control	183
	Cup holders	377
	Curtain shield airbags	103
	Customizable features	590
D	Daytime running light system	170
	Defogger	
	Rear window	256
	Side mirror	256
	Dimension	564
	Dinghy towing	237
	Display	
	Energy flow	29
	Multi-information display	166
	Touch screen	240
	Trip information	167
	Warning message	519
	Do-it-yourself maintenance	
	Door courtesy lights	369
	Door pocket	378

	Doors	Engine	
	Door lock39, 51, 54	ACCESSORY mode	149
	Rear door child protector55	Compartment	438
	Driver's seat belt reminder light 512	Hood	435
	Driver's seat position memory66	How to start the	
	Driving	hybrid system	148
	Correct posture101	If the hybrid system	
	Procedures138	will not start	547
	DVD player/changer283	Overheating	557
		Power (ignition) switch	148
Ε	Electric power steering214	Engine compartment cover	439
	Electronic key	Engine coolant temperature	
	If the electronic key does	gauge	159
	not operate properly550	Engine/power control unit coola	nt
	Replacing battery472	Capacity	569
	Emergency, in case of	Checking	444
	If a warning light turns on510	Preparing and checking	
	If a warning message is	before winter	232
	displayed519	Engine oil	
	If the electronic key does	Capacity	567
	not operate properly550	Checking	44(
	If the hybrid system	Preparing and checking	
	will not start547	before winter	232
	If the shift lever cannot be	Engine oil maintenance data	442
	shifted from "P"548	Enhanced vehicle stability	
	If the 12 volt battery is	control	
	discharged553	Event data recorder	508
	If you have a flat tire536,546		
	If you lose your keys549	First-aid kit storage belt	392
	If you think something is	Floor mats	39
	wrong507	Fluid	
	lf your vehicle becomes stuck 560	Brake	446
	If your vehicle needs to be	Washer	45
	towed501	Fog lights	
	If your vehicle overheats557	Switch	172
	Energy monitor29	Wattage	573

	Foot light3	69
	Front passenger occupant	
	classification system	115
	Front passenger's seat belt	
	reminder light	512
	Front seats	
	Adjustment	.64
	Driver's seat position memory	66
	Front turn signal lights	
	Wattage5	73
	Fuel	
	Capacity5	66
	Fuel gauge1	59
	Gas station information6	20
	Information5	74
	Refueling	91
	Messages5	30
	Fuel door	91
	Fuel filler door	91
	Fuses4	74
G		.0.4
G	Garage door opener3	
	Gas station information6	
	Gauges1	
	Glove box3	1/3
Н	Hands-free system	
	(for cellular phone)3	23
	Head restraints	
	Headlight aim4	
	Headlight cleaner1	
		-

Headlights	
Adaptive front lighting system17C)
Discharge headlights	
precautions497	,
Replacing light bulbs492	,
Switch169)
Wattage573	Ó
Heaters	
Seat heaters386)
Side mirror256)
Hill-start assist control214	+
Hood435	,
Hooks	
Cargo392)
Shopping bag392)
Horn158	j
Hybrid system24	-
Emergency shut off system29)
Energy monitor/consumption	
screen29)
High voltage components28	;
Power meter159	
Power (ignition) switch148	j
Identification	
Engine565)
Electric motor565)
Vehicle565)
Ignition switch	
Power switch148	j
Illuminated entry system369	
I/M test431	
Immobilizer system96	
Indicator lights163	,

Initialization

Items to initialize

607

.596

	Inside rear view mirror	82	М	Maintenance	
	Instrument panel light control	160		Do-it-yourself maintenance	432
	Interior lights			General maintenance	
	Interior lights	370		Maintenance data	564
	Wattage	573		Maintenance requirements	426
	Intuitive parking assist	195		Meter	
				Instrument panel light control	160
J	Jack			Meters	159
	Positioning a floor jack	436		Micro dust and pollen filter	252
	Vehicle-equipped jack			Mirrors	
	Jack handle			Inside rear view mirror	82
				Side mirror heater	256
Κ	Keyless entry	51		Side mirrors	83
• •	Keys	01		Vanity mirrors	380
	If the electronic key does			Moon roof	8
	not operate properly	550		MP3 disc	279
	If you lose your keys			Multi-information display	166
	Key number plate				
	Keys		Ν	Noise from under the vehicle	18
	Mechanical key				
	Power (ignition) switch		0	Odometer	159
	Wireless remote control key.			Oil	
				Engine oil	440
	Lexus Link System	404		Opener	
_	Light bulbs	404		Fuel filler door	9 ⁻
	Replacing	402		Hood	
	Wattage			Trunk	
	Light sensitive optitron meter			Outer foot lights	
	Lights	101		Outside rear view mirrors	
	Fog light switch	172		Adjusting and folding	83
	Headlights switch			Mirror position memory	
	Interior lights list			Outside temperature	
	Replacing light bulbs			display	382
	Turn signal lever			Overhead console	
	Vanity lights			Overheating, Engine	
	Wattage			<i>5, 9</i>	
608	**allage				

Р	Parking brake15	7
	Parking lights	
	Replacing light bulbs49:	
	Switch169	9
	Wattage573	3
	Personal lights37	1
	Portable music player31	9
	Power meter159	9
	Power outlet38!	5
	Power windows8!	5
	Pre-collision system22	!1
R	Radar cruise control183	3
	Radiator44!	5
	Radio26	1
	Radio data system263	3
	Rear sunshade389	9
	Rear turn signal lights	
	Replacing light bulbs49:	2
	Wattage573	3
	Rear view monitor system210	Э
	Rear window defogger250	5
	Replacing	
	Electronic key battery472	2
	Fuses474	4
	Light bulbs493	2
	Reporting safety defects for	
	U.S. owners598	3
S	Seat belts	
	Adjusting the seat belt74	4
	Automatic locking retractor7	
	Child restraint system	_
	installation125	5
	Cleaning and maintaining	J
	the seat belts424	4
	12	'

Emergency locking retractor	76
How to wear your seat belt	
How your child should wear	
the seat belt	77
Pre-collision seat belts	
Pregnant women,	
proper seat belt use	76
Reminder light	
Seat belt extenders	
Seat belt pretensioners	
Seat heaters/ventilators	
Seating capacity	
Seats	
Adjustment	64
Adjustment precautions	
Child seats/child restraint	
system installation	125
Cleaning	
Driver's seat position memory	
Head restraint	
Properly sitting in the seat	
Seat heaters	
Service reminder indicators	
Shift lever	
If the shift lever cannot be	
shifted from "P"	548
Transmission	
Shift lock system	
Shopping bag hooks	
Side airbags	
Side marker lights	
Switch	169
Side mirror	
Adjusting and folding	83
Mirror position memory	

Smart access system with	
push-button start	
Antenna location	41
Entry function	39
Starting the	
hybrid system	148
Spare tire	
Inflation pressure	572
Storage location	537
Spark plug	569
Specifications	564
Speedometer	159
Steering wheel	
Adjustment	81
Audio switches	320
Steering wheel position	
memory	66
Storage compartment	376
C. (.	
Storage feature	372
Storage leatureStuck	372
Stuck	560
Stuck If your vehicle becomes stuck	560
Stuck If your vehicle becomes stuck Sun visors	560 379
Stuck If your vehicle becomes stuck Sun visors	560 379 172
Stuck If your vehicle becomes stuck Sun visors Switch Fog light switch	560 379 172
Stuck If your vehicle becomes stuck Sun visors Switch Fog light switch Ignition switch	560 3 79 172 148
Stuck If your vehicle becomes stuck Sun visors Switch Fog light switch lgnition switch Light switches	560 3 79 172 148 169
Stuck If your vehicle becomes stuck Sun visors Switch Fog light switch Ignition switch Light switches Mode select switch	560 172 148 169 153
Stuck If your vehicle becomes stuck Sun visors Switch Fog light switch Ignition switch Light switches Mode select switch Power door lock switch	560 379 172 148 153 54 148
Stuck If your vehicle becomes stuck Sun visors	560 379 172 148 153 54 148
Stuck If your vehicle becomes stuck Sun visors	560 379 172 169 153 54 54
Stuck If your vehicle becomes stuck. Sun visors	560 379 172 169 153 54 148 85
Stuck If your vehicle becomes stuck Sun visors	560 379 172 169 153 54 148 85
Stuck If your vehicle becomes stuck. Sun visors	560 379 172 169 54 148 85 453

Tail lights	
Switch	169
Theft deterrent system	
Alarm	98
Immobilizer system	96
Theft prevention labels	100
Tire inflation pressure	572
Tire information	
Glossary	583
Size	580
Tire identification number	579
Uniform Tire Quality Grading	581
Tires	
Chains	233
Checking	452
Compact spare tire	537
If you have a flat tire536	5, 546
Inflation pressure	572
Information	577
Replacing	536
Rotating tires	452
Size	572
Snow tires	235
Tire pressure warning system	452
Tools	536
Total load capacity	231
Touch screen	240
Towing	
Dinghy towing	237
Emergency towing	501
Trailer towing	236
Tanatian anatural	21/

	Transmission	Warning lights
	If the shift lever cannot be	Anti-lock brake system511
	shifted from "P"548	Brake system510
	Mode select switch153	Charging system510
	"S" mode154	Electric power steering
	Transmission152	warning light511
	Trip meter159	Electronically
	Trunk	controlled brake system511
	Opener59	Low fuel level 512
	Trunk light60	Malfunction indicator lamp511
	Wattage573	Master warning light513
	Turn signal lights	Open door512
	Replacing light bulbs492	Pre-collision system511
	Switch156	Seat belt reminder light512
	Wattage573	SRS airbags511
		Tire pressure warning light512
٧	Vanity lights	Warning messages
	Vanity lights380	Anti-lock brake system511
	Wattage573	Brake assist511
	Vanity mirrors380	Charging system510
	Variable gear ratio steering215	Dynamic radar
	Vehicle dynamics	cruise control521
	integrated management215	Engine oil level526
	Vehicle identification number 565	Engine oil maintenance526
	Vehicle load limits231	Engine oil pressure519
	Ventilators386	Headlight520
		Hood524
W	Warning buzzers	Hybrid system519, 528
	Brake system510	Intuitive parking
	Downshifting155	assist521, 521, 531
	Open door512	Moon roof525
	Seat belt reminder512	Open door524
	······································	Parking brake525
		Pre-collision system521, 527
		Refueling530

Rear lights system	520
Smart access system with	
push-button start	532
Steering lock511, 52	
Trunk	525
VGRS	523
Washer fluid	525
Washer	
Checking	45
Preparing and checking	
before winter	232
Switch	173
Washing and waxing	420
Weight	
Cargo capacity	227
Load limits	23
Weight	564
Wheels	467
Window glasses	85
Window lock switch	54
Windows	
Power windows	85
Rear window defogger	256
Washer	173
Windshield wipers	
Position	234
Windshield wipers	173
Windshield wiper de-icer	257
Winter driving tips	232
Wireless remote control key	
Locking/Unlocking	5
Replacing the battery	
WMA disc	279